CONTENTS

1. GENERAL INFORMATION	
1.1 Functional description	2
1.2 Safe use of the dryer	2
2. INSTALLATION	
2.1 Acceptance and transportation	3
2.2 Installation site	3
2.3 Unpacking	3
2.4 Installation	3
3. START UP	
3.1 Control panel	4
3.1.1 Keys function	5
3.1.2 Condensate discharge	
parameters programming	5
3.1.3 Anomaly warning	6
3.1.4 Remote signalling alarm	6
3.2 Before start up	6
3.3 Start up	7
4. MAINTENANCE, TROUBLESHOOTING	
AND DISMANTLING	
4.1 Maintenance	7
4.2 Troubleshooting	7
4.3 Decommissioning	11
ATTACHMENTS TO THIS MANUAL	
A) Refrigerant circuit	13
B) Electric circuit diagram	15
C) Technical data sheet	37
D) Correction factors	38
E) Dryer dimensions	39
F) Basic spare parts	41



Filtrations-Separations-Technik

OPERATORS MANUAL

Direct	expansion	compressed	air	drvers
	onparioron	compressed	u	ar y 010

Models

DFLO 1,8 DFLO 2,4 DFLO 5,4

DFLO 7,2

DFLO 10,8 DFLO 14,4

DFLO 18 DFLO 22,5

DFLO 26

DFLO 36

DFLO 48

DFLO 78

DFLO 66

DFLO 100

INTRODUCTION

This manual is an integral part of the dryer you bought, and must remain with the machine even if this will be resold.

It is highly recommended that the qualified*personnel for installation maintenance and/or control will fully comply with the contents of this manual and the prevention and safety rules in force in the country where the system will be used. In this way, not only the usage of the machine will be rational, but also the service will result cost effective.

In case your dryer will present any kind of problem, please contact your local authorized FST distributor.

Please note that, when necessary, the use of original spare parts will ensure efficiency and long duration to your dryer.

Due to the continuous technological evolution, FST reserves the right to modify the specifications contained in this manual without giving previous notice.

SYMBOLS AND LABELS USED IN THE MANUAL AND ON THE DRYER

		Air inlet		Air outlet
	Read the the mach the dryer	Operators manual before attempt to start up hine and to perform any service operation on 		Pay particular attention to components or systems under pressure.
	Pay part these sy	icular attention to the indications preceded by mbols.		Pay particular attention to hot surfaces.
	Installation preceded exclusive	on, maintenance, and/or control operations d by these symbols must be performed ely by qualified personnel*.	A	Pay particular attention to the risk of electric shock.
	Ţ	Condensate drain point.	<i>↓↓</i>	Rotation direction of the fan.
	Pay part	icular attention to the risk of moving parts.		 RISK OF ELECTRIC SHOCK; DISCONNECT FROM SUPPLY SOURCE BEFORE SERVICING MOVING PART: DO NOT OPERATE WITH PANEL REMOVED
		Attention: Before performing any maintenance operation on this machine, do not forget to disconnect the electric supply, to	CAUTION	- HOT PART; DO NOT OPERATE WITH PANEL REMOVED
		refer to the Operators manual		ATTENZIONE ATTENTION IMPORTANTE ACHTUNG
			<u>/!</u> \	OGNI SETTIMANA ONCE A WEEK TOUTES LES SEMAINES CADA SEMANA WOCHENTLICH
(p. 4)			IL C	ONDENSATORE VA PULITO CON UN GETTO DI ARIA COMPRESSA. IE CONDENSER MUST BE CLEANED BY BLOWING OUT WITH AIR. NETTOYER LE CONDENSEUR AVEC UN JET D'AIR COMPRIME'
	Đe			LIMPIAR EL CONDENSATOR CON AIRE COMPRIMIDO. DEN KONDENSATOR MIT EINEM DRUCKLUFTSTRAHL REINIGEN.
	- Turn main power switch on position 1. - Wait for 8 hours before starting the dryer.			

* Qualified personnel must be trained and certified in accordance with local laws and regulations.

WARRANTY

The Company warrants that the equipment manufactured by it and delivered hereunder will be free of defects in material and workmanship for a period of twelve months from the date of placing the Equipment in operation or eighteen months from the date of shipment from the factory, whichever shall first occur. The Purchaser shall be obligated to promptly report any failure to conform to this warranty, in writing to the Company in said period, whereupon the Company shall, at its option, correct such nonconformity, by suitable repair to such equipment or, furnish a replacement part F.O.B. point of shipment, provided the Purchaser has stored, installed, maintained and operated such Equipment in accordance with good industry practices and has complied with specific recommendations of the Company. Accessories or equipment furnished by the Company, but manufactured by others, shall carry whatever warranty the manufacturers have conveyed to the Company and which can be passed on to the Purchaser. The Company shall not be liable for any repairs, replacements, or adjustments to the Equipment or any costs of labor performed by the Purchaser or others without Company's prior written approval.

The effects of corrosion, erosion and normal wear and tear are specifically excluded. Performance warranties are limited to those specifically stated within the Company's proposal. Unless responsibility for meeting such performance warranties are limited to specified tests, the Company's obligation shall be to correct in the manner and for the period of time provided above.

THE COMPANY MAKES NO OTHER WARRANTY OR REPRESENTATION OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE HERBY DISCLAIMED.

Correction by the Company of nonconformities whether patent or latent, in the manner and for the period of time provided above, shall constitute fulfillment of all liabilities of the Company for such nonconformities whether based on contract, warranty negligence, indemnity, strict liability or otherwise with respect to or arising out of such Equipment.

The Purchaser shall not operate Equipment which is considered to be defective, without first notifying the Company in writing of its intention to do so. Any such use of Equipment will be at Purchaser's sole risk and liability.

Note that this is FST standard warranty. Any warranty in force at the time of purchase of the equipment or negotiated as part of the purchase order may take precedence over this warranty.

1. GENERAL INFORMATION

1.1 FUNCTIONAL DESCRIPTION

FST refrigerated air dryers remove moisture from compressed air. Moisture is detrimental to pneumatically operated appliances, controls, instruments, machinery and tools.

Compressed air enters the patented aluminum heat exchanger where it is cooled down to the dew point temperature in two different stages: In the first air/air sector compressed inlet air is cooled thanks to the colder compressed air coming out counterflow from the condensate separator. In the second refrigerant / air sector, compressed air temperature is further lowered to the dew point temperature. During this two stages almost all the oil and water vapours contained in compressed air are condensed to liquid and successively be separated from the compressed air in the condensate separator and drained out by the automatic drain. At this point the obtained cold air re-enters counterflow the initial air / air exchanger and it is reheated by the inlet hot air with the consequence of energy recovering and also reduction of the relative humidity contained in the outflowing air.

This dryer can be easily installed into various pneumatic systems in which dry air is required or desired. Please refer to Principles of Operation for complete operating details.

The dryer comes provided with all the control, safety and adjustment devices, therefore no auxiliary devices are needed.

A system overload not exceeding the maximum operative limits can worsen the operational performance of the dryer (high dew point), but it will not affect its safety.

The electric diagram (attachment B) shows the minimum protection degree IP 42.



Improper grounding can result in electrical shock and can cause severe injury or death. This product must be connected to a grounded, metallic, permanent wiring system or an equipment-grounding terminal or

lead on the product. All grounding must be performed by a gualified electrician and comply with national and local electrical codes.

In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current.

Ground must be established with a bare grounding wire sized according to the voltage and minimum branch circuit requirements.

Ensure good bare metal contact at all grounding connection points, and ensure all connections are clean and tight. Check grounding connections after initial installation and periodically thereafter to ensure good contact and continuity has been maintained.

Check with a qualified electrician or service technician if the grounding instructions are not completely understood, or if in doubt as to whether the product is properly grounded.



This dryer is designed to work only with compressed air. For a different use, please contact your distributor FST.

1.2 USE OF THE MACHINE IN SAFE CONDITIONS

This system has been designed and manufactured in compliance with the European safety directive in force, therefore any installation, use and maintenance operations must be performed respecting the instructions contained in this manual.

Because an air dryer is pressurized and contains rotating parts, the same precautions should be observed as with any piece of machinery of this type where carelessness in operation or maintenance could be hazardous to personnel. In addition to obvious safety rules that should be followed with this type of machinery, safety precautions as listed below must be observed:



- 1. Only qualified personnel shall be permitted to adjust, perform maintenance or repair this air dryer.
- 2. Read all instructions completely before operating unit.
- 3. Pull main electrical disconnect switch and disconnect any separate control lines, if used, before attempting to work or perform maintenance on the unit.
- 4. Do not attempt to service any part while machine is in an operational mode.
- 5. Do not attempt to remove any parts without first relieving the entire air system of pressure.
- 6. Do not attempt to remove any part of the refrigeration system without removing and containing refrigerant in accordance with the EPA and local regulations.
- 7. Do not operate the dryer at pressures in excess of its rating.
- 8. Do not operate the dryer without guards, shields and screen in place.
- 9. Inspect unit daily to observe and correct any unsafe operating conditions.

2. INSTALLATION

2.1 ACCEPTANCE AND HANDLING

Upon receiving your FST air dryer, please inspect the unit closely. If rough handling is detected, please note it on your delivery receipt, especially if the dryer will not be uncrated immediately. Then obtain the freight carrier's signed agreement to any noted damages: this is a precondition for any insurance claims by the customer.

It is mandatory to keep the dryer always in vertical position, as indicated by the symbols present on the packaging. For handling, use devices having sufficient capacity for the weight of the machine.

Remove the packaging after having positioned the dryer in the installation site. For unpacking, refer to section 2.3.

Under no circumstances should any person attempt to lift heavy objects without proper lifting equipment (i.e., crane, hoist, slings or fork truck). Lifting any unit without proper lifting equipment, may cause serious injury. Use fork lift channels where provided.

2.2 STORAGE AND INSTALLATION LOCATION

If not in use, the dryer can be stored in its packaging in a dust free and protected site between 32°F (0°C) and 120 °F (50 °C), and a specific humidity not exceeding 90 %. Should the stocking time exceed 12 months, please contact your local FST authorized distributor.

If the dryer is not used, it will be placed in a site with the following conditions.



- The machine must be protected from atmospheric agents and not directly exposed to sun light.
- A seating base flat and capable to hold the weight of the machine.
- Ambient temperature complying with the nominal data of the dryer. The dryer should be located in a clean area, without forced air draft that can affect the fan control system.
- Make sure to leave sufficient clearance (20 inches, 500 mm) around the dryer in order to allow an adequate cooling of the machine and for maintenance and/or control operations.



The incoming air must be free from smoke or flammable vapours which could lead to explosion or fire risks.

2.3 UNPACKING

The packaging is made of carton or of cellophane. We recommend that you keep the original packaging for the device in case it has to be transported to another location or sent to a service center. Dispose the various packaging materials in compliance with the relevant rules locally in force.

- unpack the device, removing the strapping from the carton. Always wear safety gloves when using scissors or other tools to cut the straps or the cellophane;
- remove the carton or the cellophane; •
- in case it's necessary another handling of the device, refer to section 2.1;
- remove the pallet (if present);
- remove the operating manual, accessories and key from the device.

2.4 INSTALLATION

Before attempting any installation operation, make sure that:

- No parts of the air system are under pressure.
- No parts of the system are electrically powered.
- Tubing to be connected to the dryer are free of impurities.
- The pipes to be connected to the dryer does not weigh on the device.
- All interconnecting piping has been tightened.

After having verified the points listed above, you can proceed to the installation of the machine:

- 1. Connect the dryer to the compressed air lines. If not already existing, we suggest to install a by-pass allowing to isolate the machine from the plant, thus to facilitate eventual maintenance operations.
- Perform the electrical connection in accordance with any local laws and regulations after reviewing the dryer 2. electrical specifications and wiring diagram. In particular, if the power cord has no plug, install a disconnecting device (DFLO 1,8-26)
- 3. Check the condensate drainage assembly, and connect the drain flexible hose to the draining line, keeping in mind that the condensate separated by the dryer may contain oil, therefore, in order to dispose of it in compliance with the local rules in force, we suggest installing a water-oil separator having adequate capacity.
- Power the dryer after having checked that the nominal voltage and line frequency are constant and matching 4. the nominal values of the machine. The user must provide the installation with an adequate line protection and a ground terminal complying with the electrical rules locally in force.



In order to optimise the use of the dryer, we suggest to place it in such a way that all the control instruments of the machine will result easily visible.



A suitably sized prefilter must be installed before the dryer. Failure to install and maintain a proper prefilter will void the dryer warranty. The rating for this filter must be at least 10 micron.

It is necessary for the user to install a protective device (a safety accessory) to protect the equipment under pressure from the risk of exceeding the maximum allowable pressure (PS); it is necessary to install a protective device to protect the equipment at high temperature from the risk of exceeding the maximum allowable temperature.

3. START UP

Ensure that the dryer is by-passed, or there is no load on the cooler.

Switch on the main electrical isolation switch (if present). The control panel will show the message OFF, indicating that the line and control voltages are available.

Start sequence

The dryer will initially start by pressing and holding the local ON/OFF button. The start sequence will progress only if there are no active alarms. The compressor motor will start AFTER 120 SECONDS. The fan motor will start simultaneously with the compressor for DFLO 22,5-66 models, after 30 seconds for smaller models.

Mod.DFLO 78-100: the fan motor is controlled only by the fan pressure switch.

Stop sequence

The dryer can be stopped locally from the control panel. After having pressed the ON/OFF switch for 1 second, the compressor and the fan motor (only the compressor on DFLO 78-100) keep on running for further 10 seconds in order to re-balance the internal pressures. The dryer can be also stopped due to an alarm or energy saving condition (ESA or ES2). Any alarm will de–energize the compressor, fan motor can still running (only on DFLO 1,8-66), it depends on the type of alarm (see Display indications chapter). If the shutdown is due to an alarm, a message will blink on display indicating the reason for the shutdown. Energy saving condition (ESA or ES2) occurs when the dew point stands below the set value for a long time in order to save energy and avoid heat exchanger freezing. This situation can happen when ambient temperature is low and there is no compressed air load. Mod.DFLO 78-100: the fan motor is controlled only by the fan pressure switch.

Variable speed fan control (Mod. DFLO 1,8-66)

A patented microprocessor allows to adjust dryer's cooling capacity by changing the fan motor speed. If the dew point is greater than the set value, the fan speed is increased, if the dew point is smaller than the set value, the fan velocity is decreased. The range can be from 0 to 100% and the higher is the fan speed, the faster the fan LED blinks, you can read the exact value by pressing the UP button. If the velocity is 100% you will read FL (Full Load). Under load standard condition the fan speed is usually at 100%, if there is no load the fan velocity can oscillate between 0 and 20%.

In models DFLO 22,5-66, in order to adjust the greater dryer's cooling capacity, a hot gas by-pass valve cooperates with the variable speed system.

3.1 CONTROL PANEL

The dryers are provided with an electronic control system. All adjustments and resets can be performed by means of the digital panel located on the front of the dryer. The control panel is composed of 5 keys (ON/OFF, TEST, SET, DOWN and UP) and a 3 digit display, with three signalling LEDs indicated by icons (PIC 1)

Bild. 1



DISPLAY VISUALIZATION AND SIGNALLING LEDS (DFLO 1,8 ÷ DFLO 66)

DISPLAY	DESCRIPTION		
ESR the unit is in ENERGY SAVING mod			
[]n	the unit is ON with low load		
[]n_	the unit is ON with normal load		
<u>On:</u>	the unit is ON with normal-high load		
Oni	the unit is ON with high load		

LED	STATUS	DESCRIPTION
ON		Compressor energized
	Blinking	Programming mode activated
Хø	ON Condensate drain energized	
	ON	Speed of the fan = 100%
S.S.	Blinking	Speed of the fan < 100%
	OFF	Fan not running

DMN FST Kaeltetrockner DFLO1,8-100 (Rev-05A) - EN-20121100

DISPLAY VISUALIZATION AND SIGNALLING LEDS (Mod. DFLO 78 ÷ DFLO 100)

DISPLAY	DESCRIPTION		
ESA	the unit is in ENERGY SAVING mode		
0n	the unit is ON with low load		
0n_	the unit is ON with normal load		
<u>On:</u>	the unit is ON with normal-high load		
<u>On</u> I	the unit is ON with high load		

LED	STATUS DESCRIPTION	
Ũ	ON	Compressor energized
	Blinking	Programming mode activated
¥ъ	ON	Condensate drain energized (Not used with "No loss condensate drain")
So Not used		Not used

3.1.1 KEYS FUNCTION

TEST: When pushed for 3 sec. during normal operation, it activates the condensate drain. (Not used on No loss condensate drain)

SET: When pushed and released during normal operation, it displays the parameter C1. When pushed for 10 seconds, it allows to enter the C8 and C9 condensate drain parameters programming menu (see relevant table).

When pushed after having set new configuration values, it stores the applied modifications.

DOWN: When pushed while setting the drain set point, it decreases the displayed value of one unit per second, during the first 10 seconds, than of one unit every 0,1 sec.

When pushed for 10 seconds during normal operation, it starts an automatic test cycle of the controller.

UP: When pushed while setting the drain set point, it increases the displayed value of one unit per second, during the first 10 seconds, than of one unit every 0,1 sec.

ON / OFF: Pressed, it activates or deactivates the dryer. When the dryer is deactivated, the display shows OFF.



NOTE: when the controller is in the OFF position, some parts of the dryer may still be energized. Therefore, for safety purposes, disconnect the electrical power before performing any operation on the machine.

3.1.2 CONDENSATE DISCHARGE PARAMETERS PROGRAMMING



Push the SET key for 10 seconds to enter the parameters configuration menu: the display will show in sequence the set point value, the code of the first modifiable parameter (C8) and its value). Only if strictly necessary, use the UP and/or DOWN keys to change the displayed parameter value. Press the SET key to store the previously changed parameter value or to browse the parameters without

Press the SET key to store the previously changed parameter value or to browse the parameters without changing them.

15 seconds after the last performed operation, the controller will return automatically to the normal operation mode.

\mathbf{e}	PARAMETER	DESCRIPTION	RANGE	DEFA	ULT SET	VALUE
$\mathbf{\tilde{A}}$	C8	Delay between condensate discharges	1 ÷ 240 (min)		1	
		Time a service of few second second		DFLO 1,8-14,4	DFLO 18	DFLO 22,5-100
	C9	discharge	1 ÷ 240 (sec)	1	2	3

NOTE: Changes entered for timing values will be effective only after exiting the programming, while changes to other variables will be immediately effective.

Please remember that eventual changes to the configuration parameters of the machine could negatively affect its efficiency. Thus, changes have to be performed by a person familiar with the operation of the dryer.



WARNING FOR USER:IT'S FORBIDDEN TO ATTEMPT TO MODIFY THE OTHER CONFIGURATION PARAMETERS OF THE ELECTRONIC CONTROLLER WITHOUT AUTHORIZATION AND COLLABORATION OF FST'S AUTHORIZED DISTRIBUTOR

3.1.3 DISPLAY INDICATIONS

The controller is capable of recognizing certain types of anomalies in the drying circuit. In such cases, a message will blink on the display, alternated to the current dew point value.

MESSAGE (BLINKING)	CAUSE	OUTPUTS	ACTIONS
HtA High dew point value Alarm (delayed alarm) Refrie		Alarm output ON Refrig. Compressor output OFF	Resettable by switching off the dryer.
Ht2	Very high dew point value (immediate alarm)	Fan output ON Drain cycle standard	If problem persists call your local FST distributor.
PF1	Interruption or short circuit on the PTC probe input line	Alarm output ON Refrig. Compressor output OFF Fan output OFF Drain cycle standard	Resettable by switching off the dryer. May require replacing the faulty probe. If problem persists call your local FST distributor.
ESA	The automatic Energy saving	Alarm output OFF Refrig. Compressor output OFF	No action necessary.
ES2	mode activated due to low load	Fan output OFF Drain cycle standard	Automatic Reset
ASt Activated after repeated alarms		Alarm output ON Refrig. Compressor output OFF Fan output ON Drain cycle standard	Call your local FST distributor.

Note: PF1 has priority on all other messages.

3.1.4 REMOTE SIGNALING ALARM



The dryer control board is equipped with a dry contact for a remote alarm signal. This is normally open contact: when an alarm is detected, this contact is closed.

- Proceed as follows to activate a remote alarm output:
 - 1. The User must review the diagram below.
 - 2. Disconnect the dryer from electrical power supply, remove cover and left side panel.
 - 3. Connect the alarm circuit to the terminal blocks (See PIC.2).
 - 4. Replace cover, left side panel and reconnect power.

Alarm Output relays electric features:

Max. 250VAC / 3A - AC 15 (Amp. Inductive)



The activation of the above function is at the User's discretion. The User will purchase all necessary installation material. Any operation which needs access to the dryer must be carried out by qualified personnel.

3.2 BEFORE START UP



Before starting the machine, make sure that all operating parameters correspond to the nominal data. The dryer is supplied already tested and preset for normal operation, and it doesn't require any calibration. Nevertheless, it's necessary to check the operating performances during the first working hours.

3.3 START UP

The operations specified below must be performed after the first start up and at each start up after a prolonged inactive period of time due to maintenance operations, or any other reason.

- 1. Make sure that all instructions contained in chapters INSTALLATION SITE and INSTALLATION have been observed.
- 2. Ensure dryer by-pass is open and air inlet/outlet valves closed. (if existing).
- 3. Activate power supply and press the ON/OFF switch on the control panel for at least 1 second.

(note there is a 2 minute delay before the dryer will start after the dryer is turned on). **Only on DFLO 78-100**

- Turn main power switch on position 1.
- Wait for 8 hours before starting the dryer.

(the warranty is not valid if this procedure is not respected).

IF THE UNIT FAILS TO START MAKE SURE THAT PHASES ARE CONNECTED CORRECTLY.

- 4. Wait 5 to 10 minutes until machine has achieved its standard operating parameters.
- 5. Slowly open the air outlet valve and successively open the air inlet valve.
- 6. If existent, close the air by-pass valve.
- 7. Check if the condensate drain is working properly.
- 8. Check if all connecting pipes are properly tightened and fixed.

Before disconnecting the dryer from electrical power supply, use ON/OFF switch to stop the dryer. Otherwise wait 10 minutes before switching the dryer on again, in order to allow freon pressure to rebalance.

4. MAINTENANCE, TROUBLESHOOTING AND DECOMMISSIONING

4.1 MAINTENANCE



Attention! Perform pressure test with inert gases only (helium, nitrogen).

Before attempting any maintenance operation, make sure that:

- 1. No parts of the system are under pressure.
- 2. No parts of the system are electrically powered.



- ➔ WEEKLY OR EVERY 40 HOURS OF OPERATION
 - Verify the temperature on the control panel display is acceptable.
 - Visually check if the condensate is drained regularly.
 - Clean the filter mesh of the condensate drain system.
- → MONTHLY OR EVERY 200 HOURS OF OPERATION
 - Clean the condenser with compressed air, taking care not to damage the condenser fins.
 - At the end of the above mentioned operations, check if the dryer is working properly.
 - Check the condition of any filters installed with the dryer. Replace elements as needed.
- → YEARLY OR EVERY 2000 HOURS OF OPERATION
 - Check if the flexible tube used for condensate drainage is damaged and replace it if necessary
 - Check if all connecting pipes are properly tightened and fixed.
 - At the end of the above mentioned operations, check if the dryer is working properly.
- → EVERY 24 MONTHS OR EVERY 4000 HOURS OF OPERATION (Mod. DFLO 78 ÷ DFLO 100)
 - Replace the fan pressure switch

In case of replacement of one or more components of the device, disposed it along the eventual packaging of the replacement part, as reported in the point 4.3.

4.2 TROUBLESHOOTING

NOTE: FOLLOWING BEHAVIORS ARE NORMAL CHARACTERISTIC OF OPERATION AND NOT TROUBLES

- Variable speed of the fan (Mod. DFLO 1,8 ÷ DFLO 66)
- Display of message ESA and ES2 in case of operation without load or low load
- A 2 minute delay for dryer to start after pressing the on/off switch



Troubleshooting and eventual control and/or maintenance operations must be performed by qualified personnel.

For maintaining the refrigerating circuit of the machine, contact a refrigeration engineer.

TROUBLE	DISPLAY	POSSIBLE CAUSE	REMEDY
Control pan		No power in the line.	Restore the power in the line.
	Control panel	DFLO 78-100 Phases connected incorrectly.	Connect the phases correctly.
	blank	Problems with cabling.	Check cabling; if the trouble persists, replace it.
		Problems with the electronic control board.	Check the electronic control board; if the trouble persists, replace it.
	0FF	The dryer is off.	Turn it on by pressing the ON/OFF switch for 1 second.
		Dryer in stand-by.	Wait 2 minutes after the dryer is switched on.
		Compressed air inlet/outlet inverted.	Check if the compressed air inlet/outlet is connected properly.
		The flow rate and/or temperature of the air entering the dryer are higher than the nominal values.	Restore the nominal conditions.
		The ambient temperature is higher than the nominal values.	Restore the nominal conditions.
		The condenser is dirty.	Clean the condenser.
			Clean the condensate drainage system filter mesh.
	<u>Un:</u>	Condensate drain is not functioning	Replace the coil of the drainage solenoid valve if burned.
		Pic.3	clean or replace the drainage solenoid valve if clogged/jammed.
			Check the C8 and C9 parameters of the electronic control board; if the trouble persists, replace it.
IE SYSTEM		Condensate drain is not functioning. Pic.4-5	Check the no loss condensate drain; if the trouble persists, replace it.
		The temperature control probe is positioned improperly or faulty.	Check the probe; if the trouble persists, replace it.
		DFLO 78-100 Intervention of the high pressure switch.	Reset the high pressure switch.
IN T	HEA	Problems with cabling or with the electronic control board.	Check the cabling and the electronic control board, if the trouble persists, replace them.
ATER	HE 2	Activation of compressor's internal thermal protection.	Wait one hour and check again. If the fault persists: stop dryer and call your local FST distributor.
Ň		Problems with the electrical components of the compressor.	Check the electrical components of the compressor.
		Defective compressor.	Replace the compressor.
		The flow rate and/or temperature of the air entering the dryer are higher than the nominal values.	Restore the nominal conditions.
		The ambient temperature is higher than the nominal values.	Restore the nominal conditions.
	HFH	The condenser is dirty.	Clean the condenser.
	HF 5	The temperature control probe is positioned improperly or faulty.	Check the probe; if the trouble persists, replace it.
		Fan pressure switch defective or burned out (if present).	Turn off the dryer and call your local FST distributor.
		High pressure switch defective or burned out (if present).	Turn off the dryer and call your local FST distributor.
		Gas leakage in the refrigerating circuit.	Turn off the dryer and call your local FST distributor.
		Defective fan.	Replace the fan.
		Protection fuse burned out (if present).	Replace the fuse.
	FSD	The temperature control probe is positioned improperly or faulty.	Check the probe; if the trouble persists, replace it.
		Gas leakage in the retrigerating circuit without load.	Turn off the dryer and call your local FST distributor.
_	PF I	The temperature control probe is positioned improperly or faulty.	Check the probe; if the trouble persists, replace it.
	ASE	Series of alarms very close to each other.	Call your local FST distributor.

TROUBLE	DISPLAY	POSSIBLE CAUSE	REMEDY
<u>E50</u>		Ice formation in the evaporator.	Check the probe; if the trouble persists, replace it.
			Check the electronic control board; if the trouble persists, replace it.
	011		Contact our Service Centre to check the gas charge.
王		Clog.	Check if the compressed air inlet/outlet is connected properly.
SE IN	Πn		Check if the connecting tubing is clogged; in case proceed accordingly.
UL IN			Check if any valves are closed.
ŝ			Check the condition of any filter.
R		Air flows continuously through the condensate drainage.	Drainage solenoid valve jammed, clean or replace it.
2			Verify the condensate drainage times set on the electronic control
6			board (C8 and C9).
			Check the signal from the control board: if it is continuous, replace the control board.
			Check the no loss condensate drain; if the trouble persists,
			replace it.

IMPORTANT:

The temperature control probe is extremely delicate. Do not remove the probe from its position. In case of any kind of problem, please contact your local FST distributor

Pic.3 Drain solenoid valve



Bild.4 No loss condensate drain (Beko)





Electronic drain discharge Beko is the new discharger applicable to any compressed air systems. It eliminates the condensate without wasting compressed air. Electronic drain discharge starts automatically, without the need of any adjustment. The condensate discharge occurs to the use of an electronic sensor, which detects the amount of condensate in the integrated water collecting tank. The level sensor drives start and duration of the drainage, so preventing any wasting of compressed air. At the end of installation, put the system under pressure and push the TEST key repeatedly to eliminate the air bubbles contained in the discharger inlet fittings. Please refer to the attached CD of the discharger for complete instructions. To this discharger will be applied the Beko warranty conditions.

Pic.5 Option: No loss condensate drain (Zero Drain)





Zero Drain is the new electronic drain discharger applicable to any compressed air systems. It eliminates the condensate without wasting compressed air.

Electronic drain discharge starts automatically, without the need of any adjustment. The condensate discharge occurs to the use of an electronic sensor, which detects the amount of condensate in the integrated water collecting tank. The level sensor drives start and duration of the drainage, so preventing any wasting of compressed air. At the end of installation, put the system under pressure and push the TEST key repeatedly to eliminate the air bubbles contained in the discharger inlet fittings.

The Zero Drain unit is equipped with a remote alarm connection (dry contact, trigged when the drain is in alarm for more than 30 seconds): see terminal block diagrams (attachment B) for futher details).

Maintenance

Disconnect Dryer from 1. electrical supply and depressurize to 0 bar. 2. Unscrew and remove the electrical connector from the service unit. C 3. Unscrew 4 screws that holds the unit. 4. Remove the Service Unit from the drain. 2 1 5. Clean the filter mesh. 6. Replace the Service Unit. 7. Screw four screws into housing. 8. Connect the electrical connector. 9. Connect the dryer to power supply. 10. Pressurize dryer back to working pressure. Filter mesh 11. Press TEST button. 3 4

Zero Drain is equipped with Service Unit, which is recommended to be changed every year to ensure proper working conditions.



Should the discharger not operate correctly, try to act on the TEST key to clean the mesh filter. Never remove the discharger body. Should the malfunctioning persist, contact our Customer Service.

Before carrying out any work on the electrical parts, make sure that the main switch interrupts the electricity supply to the dryer and then affix appropriate warning signs to avoid the machine being reconnected to the electricity mains!

4.3 DECOMMISSIONING

All work on the dryer may only be carried out by specialist personnel! Follow this procedure if you need to shut down the dryer:

- Stop the device and permanently isolate it from the electricity mains;
- Disconnect the power cable;
- Take pressure off the air circuit;
- Empty the tank and the internal cooling medium circuits;
- If the device has to be dispatched, use the original or similar packaging and keep the device in an up-right position.



Before carrying out any work on the electrical parts, make sure that the main switch interrupts the electricity supply to the dryer and then affix appropriate warning signs to avoid the machine being reconnected to the electricity mains!

Please consult the contents and the safety instructions in the relevant sections of these instructions for details of the correct handling and storage of the drer. Remove any residual cooling medium from the dryer in a manner appropriate to its properties and in accordance with the legislation in force.

If the device has to be demolished: Never open the sealed cooling assembly (compressor, evaporator and condenser) if there may be any refrigerant or lubricating oil present!

end the dryer to an approved waste disposal company in accordance with current environmental protection legislation. The other materials/waste constituents must be treated in line with the provisions of the valid legislation.

ATTACHMENTS TO THE MANUAL

Legend

1A1	Electronic Controller	
1B1	Drain solenoid valve coil	
1B2	Liquid solenoid valve coil	
1B3	By-pass solenoid valve coil	
1 M 1	Refrigerant compressor	
1M2	Fan Motor	
1M3	Glycol circulator	
1P1	High pressure Switch	
1P2	Fan pressure Switch	
1Q1	Compressor circuit breaker	
1Q2	Fan circuit breaker	
1Q3	Transformer circuit breaker	
1R1	Compressor crankcase heater	
1R2	Electrical panel heater	
1R3	Condensate drain heater	
1S1	Main power switch	
1S2	Plug	
1 S 3	ZERO DRAIN Terminal blocks	
1T1-1T2-1T3	Transformer	
1V1	Solenoid drain Valve	
1V2	Liquid solenoid valve	
1V3	By-pass solenoid valve	
ACC	Tank	
СВ	Compressor box	
CBL	Cables	
CNA	Sacrificial anode	
CND	Condenser	
CNV	Fan capacitor	
CPL	Capillary tube	
EB	Electrical box	
ED	10 micron filter element	
EH	0.01 micron filter element	
EP	1 micron filter element	
EQ	5 micron filter element	
EVA	Evaporator	
F1-F2	Fuses	
FD	Air filter 10 micron	
FF	Filter dryer	
FH	Air filter 0.01 micron	
FP	Air filter 1 micron	
FQ	Air filter 5 micron	
FR	Drain screen	
FT	Noise filter	

FV	Fan motor fuse
G	Grid
GFCI	Ground fault circuit breaker
IM	Moisture indicator
K1	Contactor switch
K2	Fan contactor switch
KRC1	Protection module
MHP	High pressure manometer
MLP	Low pressure manometer
PCP	Thermal protection
PR	Air-air heat exchanger
R	Compressor relay
RB1	Freon Tap
RBF	Tap with strainer
RBS	Changeover tap
RD1	Reed sensor
REF	Fan speed regulator
RF	Phase control relais
RL	Liquid receiver
RR	Rotalock tap
RS	RS485 Interface
PB/RT	Temperature probes
SC	Heat exchanger base
SCO	Condensate separator
SH	Sensor hose
SLI	Liquid separator
SP	Schrader
SSC	Condensate drain
STC	Control panel cover
TEMP	Time setter
TH1	Thermostat
THR	Electrical box thermostat
TLT	Remote cont. Thermostat
VA	Glycol valve
VB	By-pass hot gas valve
VBA	Air by-pass valve
VE	Expansion valve
VNR	One way valves with strainer
VP	Pressostatic valve
VS	Тар
VSR	Freon safety valve
VT	Fan blade
X1-X2-X3-X4	Terminal blocks



Cod. 713.0048.03.00 - Rev. 00 DFLO 1,8 ÷ DFLO 18



Cod. 713.0034.03.00 - Rev. 00 DFLO 78 ÷ DFLO 100



<u>ار</u> ا ر	₽ \$₽	₽\$7
Condensate drain	Air inlet	Air outlet

			— · — · –
Refrigerant line	Compressed air line	Condensate drain line	Glycol line



Cod. 714.0104.01.00 - Rev. 00



Cod. 714.0104.01.02 - Rev. 00





Cod. 714.0104.06.00 - Rev. 00

DFLO 1,8 ÷ DFLO 18 (230V/1Ph/60Hz)



Cod. 714.0104.06.01 - Rev. 0A





ED 180 CONNECTION ONLY

Cod. 714.0104.05.00 - Rev. 00

DFLO 1,8 ÷ DFLO 14,4 (115V/1Ph/60Hz)



Cod. 714.0104.05.01 - Rev. 00







Cod. 714.0104.09.00 - Rev. 01 DFLO 18 (115V/1Ph/60Hz)



Cod. 714.0104.09.01 – Rev. 01 DFLO 18 (115V/1Ph/60Hz) – No loss option





Cod. 714.0170.03.00 - Rev. 01 DFLO 36 (230V/1Ph/50Hz)



Cod. 714.0170.11.00 - Rev. 01

DFLO 36 (230V/1Ph/50Hz) - No loss option



DFLO 36 (230V/1Ph/60Hz)



DMN FST Kaeltetrockner DFLO1,8-100 (Rev-05A) - EN-20121100

Cod. 714.0170.09.01 - Rev. 01

DFLO 36 (230V/1Ph/60Hz) - No loss option



DMN FST Kaeltetrockner DFLO1,8-100 (Rev-05A) - EN-20121100

Cod. 714.0171.04.00 - Rev. 01

DFLO 48 (230V/1Ph/50Hz)



Cod. 714.0171.06.00 - Rev. 01

DFLO 48 (230V/1Ph/50Hz) - No loss option



DMN FST Kaeltetrockner DFLO1,8-100 (Rev-05A) - EN-20121100

DFLO 48 (230V/1Ph/60Hz)



Cod. 714.0171.02.01 - Rev. 01

DFLO 48 (230V/1Ph/60Hz) - No loss option



REAR VIEW

Vista da "A" View from

DFLO 66 (230V/1Ph/50Hz)



Klemmenplan





Baugruppenanordnung







Vista da "A" View from



Vista da "B" View from

PANNELLO DI CONTROLLO CONTROL PANNEL

DFLO 66 (230V/1Ph/60Hz)





Components layout





Vista da "B" View from

PANNELLO DI CONTROLLO CONTROL PANNEL





QUADRO ELETTRICO (INTERNO) ELECTRICAL BOX (INTERNAL)

Cod. 714.0192.01.00 - Rev. 01

DFLO 78 ÷ DFLO 100 (400V/3Ph/50Hz)

Power Circuit



Control Circuit diagram







Components layout



Vista da "B" View from

PANNELLO DI CONTROLLO CONTROL PANNEL
 151
 F1
 F3

 101
 102
 F1

 K1
 K2
 1T1

 K1
 K2
 T1

Vista da "A" View from

QUADRO ELETTRICO (INTERNO) ELECTRICAL BOX (INTERNAL)

Cod. 714.0219.01.00 - Rev. 02

DFLO 78 ÷ DFLO 100 (460V/3Ph/60Hz)

Power Circuit





Terminal blocks





Components layout











QUADRO ELETTRICO |INTERNO| ELECTRICAL BOX |INTERNAL|

PANNELLO DI CONTROLLO CONTROL PANNEL



DATA SHEET

	MODEL		DFLO 1,8	DFLO 2,4	DFLO 5,4	DFLO 7,2	DFLO 10,8	DFLO 14,4	DFLO 18	
AR	Air flow rate	NI/min Nm³/h	300 18	400 24	900 54	1200 72	1800 108	2400 144	3000 180	
CONN	Air connections	BSP	3/8"	3/8"	1/2"	1/2"	3/4"	3/4"	3/4"	
REF	Refrigerant	Туре				R134a				
W	Weight	Kg	19	19	26	28	36	42	44	
AIR T	Air inlet temp.	°C				35 (Max 55	5)			
AMB T	Ambient temp.	°C				25 (Max 45	5)			
PRESS W	Working pressure	bar				7 (Max 16)			
DEWP	Pressure dew point	°C				3				
DB(A)	Sound pressure level	dB(A)				< 70				
POW SUPPLY	Power supply	V/Ph/Hz				230/1/50				
kW	Nom. consumption	KW	0,	12	0,14	0,17	0,	,41	0,50	
Max kW	Full load consumpt.	KW	0,	17	0,21	0,24	0,	,63	0,68	
RLA	Nom. Current	А	0,	90	0,96	1,13	2,	,47	3,33	
FLA	Full load current	А	1,	04	1,19	1,39	3,	,36	4,1	
LRA	Locked rotor current	А	8,	50	9	15	2	20	21	
POW SUPPLY	Power supply	V/Ph/Hz				230/1/60				
kW	Nom. consumption	KW	0,	13	0,	24	0,	,50	0,58	
Max kW	Full load consumpt.	KW	0,	19	0,	37	0,	,73	0,83	
RLA	Nom. Current	А	0,	83	1,46		3,01		3,77	
FLA	Full load current	А	1,	07	1,	89	3,	,90	5,00	
LRA	Locked rotor current	А	8,	00	16	.50	17	,60	26,00	
POW SUPPLY	Power supply	V/Ph/Hz				115/1/60				
kW	Nom. consumption	KW	0,	16	0,21	0,37	0,48	0,57	0,71	
Max kW	Full load consumpt.	KW	0,	22	0,27	0,49	0,66	0,75	1,14	
RLA	Nom. Current	А	1,	89	2,51	4,23	5,63	6,56	8,16	
FLA	Full load current	А	2,	21	2,91	5,24	6,96	7,97	11,6	
LRA	Locked rotor current	А	1	8	23	35	34	37	47	
	MODEL		DFLO 22.5	DFLO 26	DFLO 36	DFLO 48	DFLO	DFLO	DFLO 100	
AR	Air flow rate	NI/min Nm³/h	3750 225	4333 260	6000 360	8000 480	11000 660) 13000 780	16667 1000	
CONN	Air connections	BSP	1"	1"	1.1/2"	1.1/2"	2"	2"	2"	
REF	Refrigerant	Туре			I	R407C	L	ł		
W	Weight	Kg	48	49	79	85	134	164	168	
AIR T	Air inlet temp.	°C				35 (Max 55	5)	•		
AMB T	Ambient temp.	°C				25 (Max 48	5)			
PRESS W	Working pressure	bar			7 (N	/lax 16)			7 (Max 13)	
DEWP	Pressure dew point	°C				3				
DB(A)	Sound pressure level	dB(A)				< 70				
POW SUPPLY	Power supply	V/Ph/Hz			230/1/50			40	0/3/50	
kW	Nom. consumption	KW	0	,60	0,90		1,24		2,14	
Max kW	Full load consumpt.	KW	0	,84	1,28		1,73	;	3,47	
RLA	Nom. Current	Α	2	,70	4,60		5,90	;	3,55	
FLA	Full load current	А	3	,82	6,00		8,40	:	5,49	
LRA	Locked rotor current	A		17	28		33		45	

	MODEL		DFLO 22,5	DFLO 26	DFLO 36	DFLO 48	DFLO 66	DFLO 78	DFLO 100
AR	Air flow rate	NI/min Nm³/h	3750 225	4333 260	6000 360	8000 480	11000 660	13000 780	16667 1000
CONN	Air connections	BSP	1"	1"	1.1/2"	1.1/2"	2"	2"	2"
REF	Refrigerant	Туре		R407C		R13	4a	R40	07C
W	Weight	Kg	48	49	79	85	150	164	168
AIR T	Air inlet temp.	°C			3	35 (Max 55)			
AMB T	Ambient temp.	°C			2	25 (Max 45)			
PRESS W	Working pressure	bar			7 (Ma:	x 16)			7 (Max 13)
DEWP	Pressure dew point	°C				3			
DB(A)	Sound pressure level	dB(A)				< 70			
POW SUPPLY	Power supply	V/Ph/Hz			230/1/60			460/	/3/60
kW	Nom. consumption	KW	0),71	1,00	1,7	3	2,	64
Max kW	Full load consumpt.	KW	1	1,00 1,55 2,			9	4,	11
RLA	Nom. Current	А	3	3,39	4,73	8,	7	3	,8
FLA	Full load current	A	4	,77	7,35	13,	5	5	,8
LRA	Locked rotor current	A		20	35	50)	4	5

* Rating conditions of: 35°C (95°F) and 100 psig air Inlet, 25°C (77°F) ambient temperature

Performance and specifications: + / - 5%

AIR FLOW RATE	Air flow rate	PRESS W	Working pressure
POW SUPPLY	Power supply	PRESS MAX	Max, pressure
HP	Nominal power	DEWP	Pressure dew point
kW	Nominal consumption	REF	Refrigerant
Max kW	Full load consumption	w	Weight
RLA	Nominal Current	TOTAL A	Total current
FLA	Full load current	EVAP,TEMP	Evaporation temperature
LRA	Locked rotor current	SUCTION TEMP	Suction temperature
CONN	Air connections	FAN PRESSURE SWITCH SETTING	Fan pressure Switch setting
AIR T	Air inlet temperature	DISCH,PRESS,	Discharge pressure
AIR T MAX	Max, air inlet temperature	HP SWITCH SETTING	High pressure switch setting
AMB T	Ambient temperature	MIN CIRCUIT AMPACITY	Minimum circuit ampacity
AMB T MAX	Max, ambient temperature	DB(A)	Sound pressure level



CORRECTION FACTORS

Correcti	Correction factor for working pressure											
bar	5	6	7	8	9	10	11	12	13	14	15	16
psi	73	87	102	116	131	145	160	174	188,5	203	217	232
FC1	0,85	0,93	1	1,06	1,11	1,15	1,18	1,20	1,22	1,24	1,25	1,26
Correction °C	Correction factor for ambient temperature											
°F	77	8	- 6	95	104	107.6	113					
FC2	1,00) 0,9	96 (0,92	0,88	0,85	0,8					
Correcti	on factor fo	or inlet air t	emperatur	e								
°C	30	3	5	40	45	50	55				l	
°F	86	9	5	104	113	122	131					
FC3	1,20) 1,0	00	0,85	0,71	0,58	0,49					

Calculation of the dryer REAL FLOW RATE = nominal dryer flow rate x FC1 x FC2 x FC3 Calculation of the GIVEN FLOW RATE to select a suitable dryer = given flow rate ÷ FC1 ÷ FC2 ÷ FC3



DFLO 1,8 ÷ DFLO 2,4



DFLO 5,4 ÷ DFLO 26

332

24

BSP

50



		Α	В	С	D	Е	F	G	н	L
DFLO 5,4 ÷ DFLO 7,2	mm	390	432	441	100	85	65	45	65	12
DFLO 10,8 ÷ DFLO 18	mm	420	516	551	100	85	80	44	63	12
DFLO 22,5 ÷ DFLO 26	mm	485	595	590	125	80	70	50	65	12

<u>[</u>]			Æ
1/2" G	1/2" G	Ø 6mm	V/ph/Hz
3/4" G	3/4" G	Ø 6mm	V/ph/Hz
1" G	1" G	Ø 6mm	V/ph/Hz

V/ph/Hz

6mm

mm

305

360

408

51

40



(F) BASIC SPARE PARTS

	Model 230/1/50						
Pos	Element	335	DFLO 1,0	DFLO 2,4	DFLO 3,4	DFLO 7,2	DFLO 10,0
1A1	Electronic Controller	А	305.0055.01	305.0055.01	305.0055.01	305.0055.01	305.0055.01
RT1	Temperature probe	А	243.0034.01	243.0034.01	243.0034.01	243.0034.01	243.0034.01
1M1	Refrigerant compressor	С	201.0079.00	201.0079.00	201.0096.00	201.0085.00	201.1981.00
1M2	Fan Motor	В	210.0074.00	210.0074.00	210.0074.00	210.0074.00	210.0073.00
VT	Fan blade	В	213.0020.00	213.0020.00	213.0020.00	213.0020.00	213.0021.00
G	Grid		213.0044.01	213.0044.01	213.0044.01	213.0044.01	213.0045.01
1V1	Complete solenoid drain valve	В	240.0108.00	240.0108.00	240.0108.00	240.0108.00	240.0108.00
1B1	Drain solenoid valve coil	А	240.0102.00	240.0102.00	240.0102.00	240.0102.00	240.0102.00
CND	Condenser	С	921.0048.01	921.0048.01	921.0034.01	921.0035.01	921.0036.01
FF	Dehydrator filter	С	630.0049.00	630.0049.00	630.0049.00	630.0049.00	630.0049.00
FR	Drain screen	В	630.0041.00	630.0041.00	630.0041.00	630.0041.00	630.0041.00
SC	Heat exchanger base	С	904.0097.01	904.0097.01	904.0101.01	904.0101.01	904.0102.01
STC	Control panel cover		711.0261.01	711.0261.01	711.0260.01	711.0260.01	711.0260.01
SSC*	Condensate drain	А	345.0017.00	345.0017.00	345.0005.00	345.0005.00	345.0005.00

	Model 230/1/60	66D						
Pos	Element	33P	DFLO 1,0	DFLO 2,4	DFLO 5,4	DFLO 7,2	DFLO IV,0	
1A1	Electronic Controller	А	305.0055.01	305.0055.01	305.0055.01	305.0055.01	305.0055.01	
RT1	Temperature probe	А	243.0034.01	243.0034.01	243.0034.01	243.0034.01	243.0034.01	
1M1	Refrigerant compressor	С	201.0079.00	201.0079.00	201.0085.00	201.0085.00	201.0145.00	
1M2	Fan Motor	В	210.0074.00	210.0074.00	210.0074.00	210.0074.00	210.0073.00	
VT	Fan blade	В	213.0020.00	213.0020.00	213.0020.00	213.0020.00	213.0021.00	
G	Grid		213.0044.01	213.0044.01	213.0044.01	213.0044.01	213.0045.01	
1V1	Complete solenoid drain valve	В	240.0108.00	240.0108.00	240.0108.00	240.0108.00	240.0108.00	
1B1	Drain solenoid valve coil	А	240.0102.00	240.0102.00	240.0102.00	240.0102.00	240.0102.00	
CND	Condenser	С	921.0048.01	921.0048.01	921.0034.01	921.0035.01	921.0036.01	
FF	Dehydrator filter	С	630.0049.00	630.0049.00	630.0049.00	630.0049.00	630.0049.00	
FR	Drain screen	В	630.0041.00	630.0041.00	630.0041.00	630.0041.00	630.0041.00	
SC	Heat exchanger base	С	904.0097.01	904.0097.01	904.0101.01	904.0101.01	904.0102.01	
STC	Control panel cover		711.0261.01	711.0261.01	711.0260.01	711.0260.01	711.0260.01	
SSC*	Condensate drain	A	345.0017.00	345.0017.00	345.0005.00	345.0005.00	345.0005.00	

Model 115/1/60		660						
Pos	Element	335	DFLO 1,0	DFLO 2,4	DFLO 5,4	DFLO 7,2	DFLU IU,0	
1A1	Electronic Controller	А	305.0063.01	305.0063.01	305.0063.01	305.0063.01	305.0063.01	
RT1	Temperature probe	А	243.0034.01	243.0034.01	243.0034.01	243.0034.01	243.0034.01	
1M1	Refrigerant compressor	С	201.0182.00	201.0182.00	201.0086.00	201.0116.00	201.0146.00	
1M2	Fan Motor	В	210.0053.00	210.0053.00	210.0053.00	210.0053.00	210.0113.00	
VT	Fan blade	В	213.0020.00	213.0020.00	213.0020.00	213.0020.00	213.0010.00	
G	Grid		213.0044.01	213.0044.01	213.0044.01	213.0044.01	213.0046.01	
1V1	Complete solenoid drain valve	В	240.0106.00	240.0106.00	240.0106.00	240.0106.00	240.0106.00	
1B1	Drain solenoid valve coil	А	240.0112.00	240.0112.00	240.0112.00	240.0112.00	240.0112.00	
CND	Condenser	С	921.0048.01	921.0048.01	921.0035.01	921.0035.01	921.0037.01	
FF	Dehydrator filter	С	630.0049.00	630.0049.00	630.0049.00	630.0049.00	630.0049.00	
FR	Drain screen	В	630.0041.00	630.0041.00	630.0041.00	630.0041.00	630.0041.00	
SC	Heat exchanger base	С	904.0097.01	904.0097.01	904.0101.01	904.0101.01	904.0102.01	
STC	Control panel cover		711.0261.01	711.0261.01	711.0260.01	711.0260.01	711.0260.01	
SSC*	Condensate drain	А	345.0017.00	345.0017.00	345.0005.00	345.0005.00	345.0005.00	

Model 230/1/50		COD					
Pos	Element	33P	DFLO 14,4	DFLU 10	DFLU 22,3	DI LO 20	
1A1	Electronic Controller	А	305.0055.01	305.0055.01	305.0055.01	305.0055.01	
RT1	Temperature probe	А	243.0034.01	243.0034.01	243.0034.01	243.0034.01	
1M1	Refrigerant compressor	С	201.1981.00	201.0150.00	201.0140.00	201.0140.00	
1M2	Fan Motor	В	210.0114.00	210.0114.00	210.0114.00	210.1960.00	
VT	Fan blade	В	213.1975.00	213.1975.00	213.1975.00	213.1971.00	
G	Grid		213.0046.01	213.0046.01	213.0046.01	210.1949.00	
1V1	Complete solenoid drain valve	В	240.0108.00	240.0108.00	240.0108.00	240.0108.00	
1B1	Drain solenoid valve coil	А	240.0102.00	240.0102.00	240.0102.00	240.0102.00	
CND	Condenser	С	921.0037.01	921.0059.01	921.0040.02	921.0076.01	
FF	Dehydrator filter	С	630.0050.00	630.0050.00	630.0050.00	630.0050.00	
FR	Drain screen	В	140.0100.00	140.0100.00	140.0100.00	140.0100.00	
SC	Heat exchanger base	С	904.0102.01	904.0103.01	904.0156.01	904.0156.01	
STC	Control panel cover		711.0260.01	711.0260.01	711.0260.01	711.0260.01	
VB	By-pass hot gas valve	В	-	-	142.0120.00	142.0120.00	
SSC*	Condensate drain	А	345.0005.00	345.0005.00	345.0005.00	345.0005.00	

Model		66D	DFLO 14,4	DFLO 14,4	DFLO 18	DFLO 18	DFLO 22,5	DFLO 26
Pos	Element	33P	115/1/60	230/1/60	115/1/60	230/1/60	230/1/60	230/1/60
1A1	Electronic Controller	А	305.0063.01	305.0055.01	305.0063.01	305.0055.01	305.0055.01	305.0055.01
RT1	Temperature probe	А	243.0034.01	243.0034.01	243.0034.01	243.0034.01	243.0034.01	243.0034.01
1M1	Refrigerant compressor	С	201.0149.00	201.0145.00	201.0165.00	201.0150.00	201.0142.00	201.0142.00
1M2	Fan Motor	В	210.0113.00	210.0114.00	210.0113.00	210.0114.00	210.0114.00	210.1960.00
VT	Fan blade	В	213.0010.00	213.1975.00	213.0010.00	213.1975.00	213.1975.00	213.1971.00
G	Grid		213.0046.01	213.0046.01	213.0046.01	213.0046.01	213.0046.01	210.1949.00
1V1	Complete solenoid drain valve	В	240.0106.00	240.0108.00	240.0106.00	240.0108.00	240.0108.00	240.0108.00
1B1	Drain solenoid valve coil	А	240.0112.00	240.0102.00	240.0112.00	240.0102.00	240.0102.00	240.0102.00
CND	Condenser	С	921.0037.01	921.0037.01	921.0059.01	921.0059.01	921.0040.02	921.0076.01
FF	Dehydrator filter	С	630.0050.00	630.0050.00	630.0050.00	630.0050.00	630.0050.00	630.0050.00
FR	Drain screen	В	140.0100.00	140.0100.00	140.0100.00	140.0100.00	140.0100.00	140.0100.00
SC	Heat exchanger base	С	904.0103.01	904.0102.01	904.0103.01	904.0103.01	904.0156.01	904.0156.01
STC	Control panel cover		711.0260.01	711.0260.01	711.0260.01	711.0260.01	711.0260.01	711.0260.01
VB	By-pass hot gas valve	В	-	-	-	-	142.0120.00	142.0120.00
K 1	Contactor switch	А	-	-	242.0032.00	-	-	-
SSC*	Condensate drain	А	345.0005.00	345.0005.00	345.0005.00	345.0005.00	345.0005.00	345.0005.00



DETAIL A

Model		SSP	DFLO 36	DFLO 36	DFLO 48	DFLO 48	
POS	Element	001	230/1/50	230/1/60	230/1/50	230/1/60	
1A1	Electronic Controller	А	305.0055.01	305.0055.01	305.0055.01	305.0055.01	
RT1	Temperature probe	А	243.0034.02	243.0034.02	243.0034.02	243.0034.02	
1M1	Refrigerant compressor	С	201.0126.00	201.0137.00	201.0127.00	201.0073.00	
1M2	Fan Motor	В	240.0404.00	210 0101 00	210 0101 00	210 0101 00	
VT	Fan blade	В	210.0191.00	210.0191.00	210.0191.00	210.0191.00	
G	Grid		213.0073.00	213.0073.00	213.0073.00	213.0073.00	
1S1	Main power switch	С	250.0015.00	250.0015.00	250.0015.00	250.0015.00	
1V1	Complete solenoid drain valve	В	240.0108.00	240.0108.00	240.0108.00	240.0108.00	
1B1	Drain solenoid valve coil	А	240.0102.00	240.0102.00	240.0102.00	240.0102.00	
CND	Refrigerant condenser	С	921.0061.01	921.0061.01	921.0060.01	921.0060.01	
K 1	Contactor switch	А	-	-	242.0031.00	242.0031.00	
RBF	Drain screen	В	140.0100.00	140.0100.00	140.0100.00	140.0100.00	
SC	Heat exchanger base	С	920.0033.01	920.0033.01	920.0032.01	920.0032.01	
VB	By-pass hot gas valve	В	142.0120.00	142.0120.00	142.0121.00	142.0111.00	
FF	Dehydrator filter	С	630.0092.00	630.0092.00	630.0092.00	630.0092.00	
STC	Control panel cover		711.0260.01	711.0260.01	711.0260.01	711.0260.01	
SSC*	Condensate drain	А	345.0006.00.00	345.0006.00.00	345.0006.00.00	345.0006.00.00	



Model		000	DFLO 66	DFLO 66	DFLO 78	
POS	Element	355	230/1/50	230/1/60	400/3/50	
1A1	Electronic board	Α	305.0055.01	305.0055.01	305.0062.01	
RT1	Probe	Α	243.0034.02	243.0034.02	243.0034.02	
1M1	Frigorific compressor	С	201.0127.00	201.0073.00	203.0004.00	
1M2	Fan Motor	D	210 0101 00	210 0101 00	210 0116 00	
VT	Fan blade	Б	210.0191.00	210.0191.00	210.0118.00	
G	Grid		213.0057.00	213.0057.00	213.0056.00	
1P1	High pressure Switch	Α	-	-	245.1988.00	
1P2	Fan pressure Switch	Α	-	-	245.0077.00	
1V1	Drain solenoid valve complete	В	240.0108.00	240.0108.00	240.0110.00	
1B1	Drain solenoid valve coil	А	240.0102.00	240.0102.00	240.0111.00	
CND	Freon condenser	С	921.0041.01	921.0041.01	921.0038.01	
FF	Dehydrator filter	С	630.0130.00	630.0130.00	630.0130.00	
RBF	Tap with strainer	В	140.0100.00	140.0100.00	140.0100.00	
SC	Heat exchanger base	С	920.0066.01	920.0066.01	920.0066.01	
STC	Control panel cover		711.0260.01	711.0260.01	711.0260.01	
VB	By-pass hot gas valve	В	142.0121.00	142.0111.00	142.0133.00	
SLI	Liquid separator		-	-	910.0956.00	
F1	Primary Fuse	А	-	-	331.0041.00	
F2	24V Secondary fuse	Α	-	-	331.0032.00	
F3	Phase control relais fuse	Α	-	-	331.1969.00	
RF	Phase control relais	С	-	-	251.1018.00	
K1	Contactor switch	Α	242.0031.00	242.0031.00	252.0056.00	
K2	Fan contactor switch	Α	-	-	252.0054.00	
1R1	Compressor crankcase heater	С	-	-	230.0016.00	
1T1	Transformer	С	-	-	241.0048.00	
IM	Moisture indicator	С	-	-	-	
SSC*	Condensate drain	С	045.D040.GB31.4	045.D040.GB31.4	045.D040.GB33.4	
(ZERO)	Service kit	Α	904.0163.01.00	904.0163.01.00	904.0163.03.00	
SSC* (BEKO)	Condensate drain	А	345.0006.00.00	345.0006.00.00	345.0008.00.00	

Model		000	DFLO 78	DFLO 100	DFLO 100	
POS	Element	395	460/3/60	400/3/50	460/3/60	
1A1	Electronic board	А	305.0062.01	305.0062.01	305.0062.01	
RT1	Probe	А	243.0034.02	243.0034.02	243.0034.02	
1M1	Frigorific compressor	С	203.0004.00	203.0004.00	203.0004.00	
1M2	Fan Motor	P		210 0116 00		
VT	Fan blade	Ь	210.0197.00	210:0110:00	210.0197.00	
G	Grid			213.0056.00		
1P1	High pressure Switch	А	245.1988.00	245.1988.00	245.1988.00	
1P2	Fan pressure Switch	Α	245.0077.00	245.0077.00	245.0077.00	
1V1	Drain solenoid valve	В	240.0110.00	240.0110.00	240.0110.00	
1B1	Drain solenoid valve coil	А	240.0111.00	240.0111.00	240.0111.00	
CND	Freon condenser	С	921.0038.01	921.0038.01	921.0038.01	
FF	Dehydrator filter	С	630.0130.00	630.0130.00	630.0130.00	
RBF	Tap with strainer	В	140.0100.00	140.0100.00	140.0100.00	
SC	Heat exchanger base	С	920.0066.01	920.0062.01	920.0066.01	
STC	Control panel cover		711.0260.01	711.0260.01	711.0260.01	
VB	By-pass hot gas valve	В	142.0133.00	142.0133.00	142.0133.00	
SLI	Liquid separator		910.0956.00	910.0956.00	910.0956.00	
F1	Primary Fuse	А	331.0041.00	331.0041.00	331.0041.00	
F2	24V Secondary fuse	А	331.0032.00	331.0032.00	331.0032.00	
F3	Phase control relais fuse	А	331.1969.00	331.1969.00	331.1969.00	
RF	Phase control relais	С	251.1018.00	251.1018.00	251.1018.00	
K1	Contactor switch	А	252.0056.00	252.0056.00	252.0056.00	
K2	Fan contactor switch	А	252.0054.00	252.0054.00	252.0054.00	
1R1	Compressor crankcase heater	С	230.0019.00	230.0016.00	230.0019.00	
1T1	Transformer	С	241.0082.00	241.0048.00	241.0082.00	
IM	Moisture indicator	С	-	-	-	
SSC	Condensate drain	С	045.D040.GB33.4	045.D040.GB33.4	045.D040.GB33.4	
(ZERO)*	Service kit	А	904.0163.03.00	904.0163.03.00	904.0163.03.00	
SSC* (BEKO)	Condensate drain	А	345.0008.00.00	345.0008.00.00	345.0008.00.00	

